



Custom Dynamics® Fog Light Mounting Clamp Installation Instructions

We thank you for purchasing the Custom Dynamics® Fog Light Mounting Clamp. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1 (919) 554-0949.

Part Numbers: CD-125-B CD-125-C

Package Contents:

- Fog Light Mounting Clamps (2)
- 3mm Allen Head Screws (4)
- 2.5mm Set Screws (2)
- 3mm Hex Wrench (1)
- 2.5mm Hex Wrench (1)
- 8mm-1.25 x 25mm Button Head Bolt (2)
- Small OD Washers (2)
- Nord Lock Washers (2)
- Instructions (1)

Fitment: Universal mount to 1.25" engine guards. 5/16" mounting hole. Hardware supplied for compatibility with Custom Dynamics® ProBeam® Fog Lights and Shark Demon® Fog Lights (sold separately).



ATTENTION



Please read all Information below before Installation

Warning: Remove seat and disconnect the negative battery cable from the battery; failure to do so may result in electrical shock, injury or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on motorcycle.

Safety First: Make sure the motorcycle is parked on a level surface and motorcycles mechanical components are cool to the touch.

Cleaning: Never use abrasive polishes or cleaners (e.g. "bug off" cleaners) as they can scratch and/or damage the finish, voiding warranty coverage. Avoid power washing/applying direct stream to after-market parts.

Notice: Hand start all bolts, **DO NOT** use impact wrench/"zip gun" when installing.

Notice: Always wear appropriate safety gear including safety glasses when soldering or performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Please read all instructions before starting project.

Note: Mounting studs are 5/16" in diameter, please verify your mounting clamp hole before installation.



Installation:

1. Remove the seat and disconnect the negative battery cable from the battery.
2. Install the Custom Dynamics® Fog Light Mounting Clamps on motorcycles engine guard by fitting both clamp halves around the tube and using supplied 3mm Allen Head Screws to fasten clamp using supplied 3mm Hex Wrench to tighten and finally use the supplied 2.5mm Set Screws and 2.5mm Hex Wrench to lock them in place.
3. Install the Custom Dynamics® ProBEAM® LED Halo Fog Lights or Shark Demon® Fog Lights (sold separately) to the Custom Dynamics® Fog Light Mounting Clamps with a maximum diameter of 5/16" hole. Refer to the Custom Dynamics® Fog Light instructions for installation. Custom Dynamics® Fog Light Mounting Clamps with Custom Dynamics® Shark Demon® LED Fog Lamps shown in **Figure 1**. **Note: When installing Shark Demon® Fog Lights use supplied 8mm-1.25 x 25mm Button Head Screws, Small OD Washers and Nord Locks (Nord Locks go in-between the SD Fog Light and Mounting Clamp to prevent rotation).**



Questions? Email: info@CustomDynamics.com or Call us at: 1 (919) 554-0949 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST