

# Custom Dynamics® 18+ Softail Parts & Accessories Y-Harness Installation Instructions



## Part Numbers

CD-18ST-Y

## Package Contents

Custom Dynamics® 18+ Softail Parts & Accessories Y-Harness (1)  
Instructions (1)



## Fitment

2018-2024 Harley-Davidson® Softail Street Bob (FXBB/FXBBS), Heritage Classic (FLHC/FLHCS), Fat Boy (FLFB/FLFBS), Fat Bob (FXFB/FXFBS), 2020-2024 Softail Standard (FXST), 2020-2024 Low Rider S (FXLRS), 2022-2024 Low Rider ST (FXLRST), 2022 Low Rider El Diablo (FXRST), 2018-2020 Low Rider (FXLR), Deluxe (FLDE), Breakout (FSXB/FXSR), 2023-2024 Breakout 117 (FXBR), 2018-2021 Sport Glide (FLSB), Slim (FLSL) and 2019-2020 FXDR.

**Also Fits:** 2017-2024 Harley-Davidson® Ultra Limited (FLHTK), Road King Special (FLTRXS), Tri Glide (FLHTCUTG) and Freewheeler (FLRT), 2017-2023 Street Glide (FLHX), Street Glide Special (FLHXS), Road Glide (FLTRX), Road Glide Special (FLTRXS), 2022-2023 Street Glide ST (FLHXST), Road Glide ST (FLTRXST) and CVO Road Glide Limited (FLTRKSE), 2020-2024 Road Glide Limited (FLTRK), 2017-2019 Electra Glide Ultra Classic (FLHTCU), 2017-2019 Road Glide Ultra (FLTRU), 2017-2018 Ultra Limited Low (FLHTKL), 2017-2021 CVO Limited (FLHTKSE), 2017-2022 Road King (FLHR), 2017-2022 CVO Street Glide (FLHXSE), 2018-2022 CVO Road Glide (FLTRXSE), 2019-2022 Electra Glide Standard (FLHT), 2023-2024 Road Glide 3 (FLTRT) and 2020-2022 CVO Tri Glide Ultra (FLHTCUTGSE).

## Suggested Tools

Safety Glasses  
5/32" Allen Socket or T-Handle

## Installation

### Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Remove the seat and all necessary parts to disconnect the negative battery cable from the battery.
2. Remove the left side cover (**18+ Softail Models, Figure 1**), remove right side cover (**Touring Models, Figure 2**) to gain access to the motorcycles Parts and Accessories connector.
3. Plug in the 18+ Softail Parts and Accessories Y-Harness into the Parts and Accessories plug on the motorcycle and now you can plug in multiple accessories to the motorcycle.

### Note

For more than two accessories you can use additional CD-18ST-Y Harnesses (**sold separately**).

4. Reconnect the negative battery cable to the battery and reinstall all necessary parts. Reinstall side cover and seat.
5. Test accessories that are plugged into the Custom Dynamics® 18+ Softail Parts and Accessories Y-Harness for proper operation.

Questions? Email: [Info@CustomDynamics.com](mailto:Info@CustomDynamics.com) or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST

## Installation Instructions Continued - 2

