

Custom Dynamics® 23.5 Touring Parts & Accessories Y-Harness Installation Instructions



Part Numbers

CD-23TOUR-Y

Package Contents

Custom Dynamics® 23.5 Touring Parts & Accessories Y-Harness (1)
Instructions (1)



Fitment

2023.5-2026 Harley-Davidson® CVO Street Glide (FLHXSE), 2025 Street Glide Ultra (FLHXU), 2024-2026 Street Glide (FLHX), 2026 Street Glide Limited (FLHXL), 2026 CVO Street Glide Limited (FLHXLSE), 2026 CVO Street Glide ST (FLHXSTSE), 2026 Street Glide 3 Limited (FLHLT), 2026 CVO Street Glide 3 Limited (FLHLTSE), 2023.5-2025 CVO Road Glide (FLTRXSE), 2024-2026 Road Glide (FLTRX), 2024-2026 CVO Road Glide ST (FLTRXSTSE), 2026 Road Glide Limited (FLTRXL) and 2026 Road Glide 3 (FLTRT).

Suggested Tools

Safety Glasses

Installation

Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Remove the seat and all necessary parts to disconnect the negative battery cable from the battery.
2. Locate the Parts & Accessories connector on top of the battery tray. Shown in **Figure 1**.
3. Plug in the 23.5 Touring Parts & Accessories Y-Harness onto the motorcycle. Now you can plug in multiple accessories to the motorcycle.

Note

For more than two accessories you can use additional CD-23TOUR-Y Harnesses (**sold separately**).

4. Reconnect the negative battery cable to the battery and all necessary parts. Reinstall the left side cover and seat.
5. Test accessories that are plugged into the Custom Dynamics® 23.5 Touring Parts & Accessories Y-Harness for proper operation.

Questions? Email: Info@CustomDynamics.com or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST

