



Custom Dynamics® 7" LED Headlight Installation Instructions

We thank you for purchasing the Custom Dynamics® 7" LED Headlight. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1 (800) 382-1388.

Part Number: CD-7-13-B CD-7-13-C

Package Contents:

- Custom Dynamics® 7" LED Headlight (1)
- Mounting Ring (1)
- 6-32 Washers (8)
- Instructions (1)

Fits: 1994-2013 Harley-Davidson® Electra Glide Classic (FLHTC), Electra Glide Standard (FLHT), Electra Glide Ultra Classic (FLHTCU), Ultra Classic (FLTCU), Ultra Limited (FLHTK), CVO Electra Glide (FLHTCSE), CVO Ultra Classic (FLHTCUSE), 1995-2013 Road King (FLHR), Road King Classic (FLHRC), Road King Custom (FLHRS), CVO Road King (FLHRSE), 2006-2013 Street Glide (FLHX), CVO Street Glide (FLHXSE), 2009-2013 Tri Glide Ultra Classic (FLHTCUTG), 2010-2011 Street Glide Trike (FLHXXX), and 2012-2017 Dyna Switchback models.

Note: Road King and Switchback models require 6-32 washers for installation.



ATTENTION



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on motorcycle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure motorcycle is on level surface, secure and cool.

Note: Complies with SAE and DOT standards for high and low beam motorcycle headlamp.

Cleaning: Take special care in cleaning the finish. Never use abrasive polishes or cleaners as these can scratch the finish.



Installation:

1. Remove the seat and disconnect the negative battery cable from the battery.
2. Remove the OEM headlight and mounting bucket as an assembly. Retain OEM screws for reinstallation on new headlight.
3. Connect the Custom Dynamics® 7" LED headlight to the existing factory H4 plug and reinstall. Make sure no wire or any components of the harness can be pinched during installation. **Note:** Road King and Switchback models will require supplied 6-32 Washers for install.
5. Reconnect the negative battery cable to the battery and reinstall the seat.
6. Aim Custom Dynamics® 7" LED Headlight. **Note:** Scan the QR Code below for specific instructions on proper measurements for aiming headlight.



7. Test the new Custom Dynamics® 7" LED Headlight for proper operation.

Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2

