



## Custom Dynamics® LED Backrest Bracket Light Installation Instructions

We thank you for purchasing the Custom Dynamics® LED Backrest Bracket Light for Harley Davidson® Touring Models. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Numbers:** CD-BR-BCM-B CD-BR-BCM-C

### Package Contents:

- LED Backrest Bracket Light (1)
- Backrest Adapter Harness (1)
- 4" Cable Ties (6)
- Instructions (1)

**Fits:** 2014-2024 Harley-Davidson® Ultra Limited (FLHTK), 2014-2023 Street Glide (FLHX), Street Glide Special (FLHXS), 2015-2023 Road Glide (FLTRX), Road Glide Special (FLTRXS), 2017-2025 Road King Special (FLHRXS), 2014-2022 Road King (FLHR), 2022-2023 Street Glide ST (FLHXST), Road Glide ST (FLTRXST) & CVO™ Road Glide Limited (FLTRKSE), 2020-2024 Road Glide Limited (FLTRK), 2015-2022 CVO™ Street Glide (FLHXSE), 2018-2022 CVO™ Road Glide (FLTRXSE), 2019-2022 Electra Glide Standard (FLHT), 2014-2019 Electra Glide Ultra Classic (FLHTCU), 2015-2016 Ultra Classic Lo (FLHTCUL) & CVO™ Road Glide Ultra (FLTRUSE), 2016-2019 Road Glide Ultra (FLTRU), 2015-2018 Ultra Limited Lo (FLHTKL), 2014-2021 CVO™ Limited (FLHTKSE), 2014 CVO™ Road King (FLHRSE).

**Note:** Replaces passenger backrest bracket OEM 52565-94 only, must already have sissy bar and backrest pad.



### Installation:

1. Remove motorcycle seat.
2. Disconnect the negative battery cable from the battery.
3. Locate the rear lighting harness connectors. Plug in the included Adapter Harness inline between the male and female rear lighting harness connectors.
4. Loosen the screws securing the stock backrest bracket and remove. Save the screws for reinstallation.
5. Install the LED Backrest Bracket Light to the backrest securing the assembly with the original screws.
6. Route the LED Backrest Bracket Light quick disconnect wiring harness down the backrest and under the seat and secure wiring using the supplied 4" Cable Ties from being cut, frayed or pinched.
7. Connect the LED Backrest Bracket Light quick disconnect harness connector to the Backrest Adapter Harness.
8. Reconnect the negative battery cable to the battery.
9. Reinstall the motorcycle seat.
10. Test the Custom Dynamics® LED Backrest Bracket Light for proper operation.



Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on motorcycle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure motorcycle is on level surface, secure and cool.

**Important:** This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the motorcycle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Questions? Email: [info@CustomDynamics.com](mailto:info@CustomDynamics.com) or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST