



Custom Dynamics® LED Fork Reflectors Installation Instructions

We thank you for purchasing the Custom Dynamics® LED Fork Reflectors. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: CD-FORK-SS8-AB CD-FORK-SS8-AC
CD-FORK-SS8-SB CD-FORK-SS8-SC

Package Contents:

- LED Fork Reflector (pair)
- SS8 Adapter Harness (1)
- Wire Tie Wrap (10)



Fits: 2009-2013 Harley-Davidson® CVO™ Street Glide (FLHXSE) and CVO™ Road Glide Custom (FLTRXSE), 2013 CVO™ Road King (FLHRSE).

Installation:

1. Remove the seat and disconnect the negative battery cable from the battery.
2. Locate the rear main lighting harness to the rear fender. Unplug and install the SS8 Adapter Harness in line with the rear fender lighting.

Note: The order of installation, from front to back, will be the bike's SS8 main wiring harness, Smart Signal Stabilizer™/Load Equalizer (if installed), SS8 Adapter Harness, brake strobe module (if installed), Run/Brake/Turn module (if installed) and then the bike's rear lighting harness.

3. Remove the OEM fork reflector from the lower fork leg. Clean the reflector area removing any debris or tape from the OEM Reflector.
4. Wipe the reflector area down with denatured alcohol and let dry.
5. Remove the protective red film from the back of the LED Fork Reflectors. Align the LED Fork Reflectors in the reflector area and press into place. The LED Fork Reflector should be mounted with the wire exiting the top, rear side of the light.

Warning: Mounting the LED Fork Reflectors higher than 3.5 inches from the bottom of the fork leg will cause damage to light and will not be covered under warranty.



ATTENTION

Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2.

6. Route the wiring harness from each LED Fork Reflectors to the SS8 Adapter Harnesses under the seat.
7. Connect to the corresponding Left (Purple wire) or Right (Brown wire) male JAE Connector.
8. Using the provided wire ties, secure the LED Fork Reflector harnessed to prevent damage to the wiring harness.
9. Reconnect the negative battery cable to the battery
10. Reinstall the seat.
11. Test operation of all lighting for proper running, brake and turn before riding.