



Custom Dynamics® Indian® Low Profile BAGZ™ Installation Instructions

We thank you for purchasing the Custom Dynamics® Indian® Low Profile BAGZ™. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: CD-INDBAG-SWP-R CD-INDBAG-SWP-S
CD-INDBAG-SWN-R CD-INDBAG-SWN-S

Package Contents:

- Saddlebag LED Light W/ Quick Disconnect Harness (2)
- IND Adapter Harness (1)
- 4" Cable Tie (10)
- Cable Tie Holder (6)
- Instructions (1)

Fitment:

CD-INDBAG-SWP-R CD-INDBAG-SWP-S

NORTH AMERICA (US, CANADA & MEXICO) MODEL 2020-2025 Indian® Challenger, Challenger Dark Horse & Challenger Limited 108 models. 2020-2024 Challenger Elite, 2022-2025 Indian Pursuit Limited & Pursuit Dark Horse 108 models, 2025 Chieftain PowerPlus 108, Chieftain PowerPlus Limited 108, Chieftain PowerPlus Dark Horse 108, Roadmaster PowerPlus Dark Horse 108, Roadmaster PowerPlus Limited 108. **Does not fit 2025 PowerPlus 112 models.**

CD-INDBAG-SWN-R CD-INDBAG-SWN-S

NORTH AMERICA (US, CANADA & MEXICO) MODEL 2019-2025 Indian® Chieftain, Chieftain Limited, Chieftain Dark Horse & Roadmaster Dark Horse, 2019-2023 Chieftain Elite, 2021-2025 Roadmaster Limited, 2024 Roadmaster Elite, and 2020-2025 Springfield Dark Horse. **Does not fit International Models.**



Installation:

1. Remove all necessary parts and disconnect the negative battery cable from the battery.
2. Locate the 6 pin connector going to the rear fender lighting. Unplug and install the IND Adapter Harness in line with the rear fender lighting.

Note: The order of installation will be motorcycle's main wiring harness, brake strobe module (if installed), IND Adapter Harness, and then the motorcycle's rear lighting harness.

3. Test fit the Low Profile Saddlebag Lights. The saddlebag light with the purple wire in the harness will mount on the left saddlebag. The saddlebag light with the brown wire in the harness will mount on the right saddlebag. The light should mount a couple millimeters below the bottom edge of the lid when the lid is closed. Mark the location with a grease pencil.
4. Clean area with denatured alcohol, allow to dry.
5. Remove the red adhesive backing and install the lights on the left and right saddlebags. Press into place making sure the adhesive tape is making contact with the saddlebag.
6. Remove both bags from the motorcycle and both side covers.



ATTENTION

Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on motorcycle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure motorcycle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the motorcycle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Important: Ambient install temperature must be 60 degrees F or higher. Allow 24 hours for tape to cure before washing or prolonged use of motorcycle.

Questions? Email: Info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2

Installation Continued:

7. Select location for cable tie holders. Clean area with denatured alcohol, allow to dry. Remove paper backing for Cable Tie Holders and press into place. Shown in **Figure 1**.



8. Route wires from bag light to each Cable Tie Holder location and secure with supplied Cable Ties to keep wires from being cut, frayed or pinched.
9. Reinstall saddlebags.
10. Following the saddlebag lock wiring harness, continue routing the wires the side cover area and up to the IND adapter harness.
11. Connect the black 4 pin JAE connector from bag lights to the IND Adapter Harness. The pigtail from the IND Adapter Harness with the brown wire will connect to the right side bag light. The pigtail from the IND Adapter Harness with the violet wire will connect to the Left side bag light.
12. Secure wires under the seat with the supplied Cable Ties from being cut, frayed or pinched.
13. Reconnect the negative battery cable to the battery and reinstall all necessary parts.
14. Test the Custom Dynamics® Indian® Low Profile Saddlebags Lights for proper operation.