



Custom Dynamics® Plug and Play LED Plugz™ Installation Instructions

We thank you for purchasing the Custom Dynamics® Plug and Play LED Plugz™. Our products utilize the latest technology and high quality components to ensure you the brightest, most reliable LED's on the market. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: CD-PLUG-SB CD-PLUG-RB
CD-PLUG-SC CD-PLUG-RC

Package Contents:

- Plug and Play LED Plugz™ (2)
- 4" Cable Ties (8)
- Instructions (1)

Fitment: With Optional Adapters (Sold Separately).

- **PR-MPR-BCM Adapter:** 2014-2023 Harley-Davidson® Street Glide (FLHX), Street Glide Special (FLHXS), 2015-2023 Road Glide (FLTRX), Road Glide Special (FLTRXS) and 2017-2025 Road King Special (FLHRXS).

- **PR-MPR-SS6 Adapter:** 2010-2013 Harley-Davidson® Street Glide (FLHX) and Road Glide Custom (FLTRX).

- **PR-MPR-HD Adapter:** 2006-2009 Harley-Davidson® Street Glide (FLHX) and Road Glide Custom (FLTRX).



Installation:

1. Remove the saddlebags to allow access to the inside fascia panel.
2. Remove or relocate the OEM antenna.
3. Remove the OEM rubber plugs and/or grommets from the antenna port holes in the fascia panel. Shown in **Figures 1 and 2**.



4. Take the LED Plugz™ wires and feed through the port holes first, followed by the LED Plugz™ and push firmly into place.
5. Route wiring harness to the PR-MPR Adapter (**sold separately**). Refer to the PR-MPR instructions for installation. Secure wiring harness using supplied Cable Ties to prevent from being cut, frayed or pinched.
6. Reinstall saddlebags.
7. Test the Custom Dynamics® Plug and Play LED Plugz™ for proper operation.



ATTENTION

Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on motorcycle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure motorcycle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the motorcycle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST