

Custom Dynamics® 12V Tour-Pak® Power Port Installation Instructions



Part Number

CD-PP-TP-1

Package Contents

Custom Dynamics® 12V Power Port w/ Harness (1)
Instructions (1)



Fitment

2014-2024 Harley-Davidson® Ultra Limited (FLHTK), 2022-2023 CVO™ Road Glide Limited (FLTRKSE), 2020-2024 Road Glide Limited (FLTRK), 2014-2019 Electra Glide Ultra Classic (FLHTCU), 2015-2016 Ultra Classic Lo (FLHTCUL) and CVO™ Road Glide Ultra (FLTRUSE), 2016-2019 Road Glide Ultra (FLTRU), 2015-2018 Ultra Limited Lo (FLHTKL), 2014-2021 CVO™ Limited (FLHTKSE), 2014-2025 Tri Glide (FLHTCUTG) and 2020-2022 CVO™ Tri Glide (FLHTCUTGSE), and 2025 Street Glide Ultra (FLHXU) with OEM King Tour-Pak®. Also fits 2023-2025 Harley-Davidson® CVO Street Glide (FLHXSE), CVO Road Glide (FLTRXSE), 2024-2025 Street Glide (FLHX), Road Glide (FLTRX), and CVO Road Glide ST (FLTRXSTSE) with add on OEM King Tour-Pak® Luggage 53000775.

Suggested Tools

Safety Glasses
T20 TORX Socket or Handle Driver

Installation

Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Remove all necessary parts to disconnect the negative battery cable from the battery.
2. Open Tour-Pak® lid and remove the two lid tether screws and install the 12V Tour-Pak® Power Port under the tether and reinstall the two screws. Shown in **Figure 1 & 2**.

Note

Make sure to secure the lid while tether screws are removed, lid could open too far and cause damage to Tour-Pak®.

3. Route wires out the front left corner of the Tour-Pak® and up to the battery and connect the red lead to the positive battery terminal and the black lead to negative battery terminal.
4. Secure the wires with cable ties from being cut, frayed or pinched.

Questions? Email: Info@CustomDynamics.com or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST



5. Replace all necessary parts.
6. Test the new Custom Dynamics® 12V Tour-Pak® Power Port by connecting your phone charger to one of the ports on the 12V Power Port for proper operation.

