

Custom Dynamics® Non-Lighted Road Glide Windshield Trim Installation Instructions



Part Numbers

CD-RG-TRIM-B

Package Contents

Custom Dynamics® Non-Lighted Windshield Trim (2)
10-32 Button Head Allen Screws (4)
Plastic Washers (4)
Instructions (1)



Fitment

2015-2023 Harley-Davidson® Road Glide (FLTRX), Road Glide Special (FLTRXS), 2022-2023 Road Glide ST (FLTRXST) and CVO™ Road Glide Limited (FLTRKSE), 2020-2024 Road Glide Limited (FLTRK), 2018-2022 CVO™ Road Glide (FLTRXSE), 2016-2019 Road Glide Ultra (FLTRU), 2020-2022 CVO™ Road Glide Ultra (FLTRUSE) and 2023-2025 Road Glide 3 (FLTRT).

Suggested Tools

Safety Glasses
Phillips Screwdriver
5/32" Allen Socket or T-Handle

Installation

Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Remove and discard the 4 OEM windshield screws, they will not be reused.
2. Remove windshield to prevent it from being damaged.
3. Install the Custom Dynamics® Non-Lighted Windshield Trim using the supplied 10-32 x 0.750" Button Head Allen Screws and Plastic washers. Only start screws at this time.

Notice

Hand start all bolts, **DO NOT** use impact wrench/"zip gun" when installing.

4. Reinstall windshield under the Custom Dynamics® Non-Lighted Windshield Trim and tighten all screws.

Note

Do not over tighten windshield screws it can cause damage to windshield or Non-Lighted Windshield Trim.

Questions? Email: Info@CustomDynamics.com or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST