

Custom Dynamics® Seat Bolt Mounted Brake Light Installation Instructions



Part Numbers

Patent

CD-SBTL-BCM-S, CD-SBTL-BCM-R

Patent Pending

Package Contents

Custom Dynamics® Seat Bolt Mounted Brake Light (1)
1/4"-20 x 1.00" 12 point Bolt (1)
Adapter Harness (1)
6" Cable Ties (5)
Instructions (1)



Fitment

2014-2024 Harley-Davidson® Ultra Limited (FLHTK), 2014-2023 Street Glide (FLHX), Street Glide Special (FLHXS), 2015-2023 Road Glide (FLTRX), Road Glide Special (FLTRXS), 2017-2024 Road King Special (FLHRXS), 2014-2022 Road King (FLHR), 2022-2023 Street Glide ST (FLHXST), Road Glide ST (FLTRXST) and CVO Road Glide Limited (FLTRKSE), 2020-2024 Road Glide Limited (FLTRK), 2015-2022 CVO Street Glide (FLHXSE), 2018-2022 CVO Road Glide (FLTRXSE), 2019-2022 Electra Glide Standard (FLHT), 2014-2019 Electra Glide Ultra Classic (FLHTCU), 2015-2016 Ultra Classic Lo (FLHTCUL) and CVO Road Glide Ultra (FLTRUSE), 2016-2019 Road Glide Ultra (FLTRU), 2015-2018 Ultra Limited Lo (FLHTKL), 2014-2021 CVO Limited (FLHTKSE), 2014 CVO Road King (FLHRSE).

Note

Seat Bolt Mounted Brake Light is only visible with Tour-Pak® removed.

Suggested Tools

Safety Glasses
Phillips Screwdriver
5/16" 12-Point Socket

Installation

Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Remove all necessary parts to disconnect the negative battery cable from the battery.
2. Remove the seat.
3. Unplug the rear lighting connector located on top of battery black connector. Shown in **Figure 1**.
4. Connect the Adapter Harness in-line to the right rear turn signal connector.
5. Connect the Seat Bolt Mounted Brake Light wire to the Adapter Harness. Shown in **Figure 2**.
6. Route wire and Seat Bolt Mounted Brake Light back to the seat bolt mount. Shown in **Figure 2**.
7. Secure the wires with the supplied 6" Cable Ties from being cut, frayed or pinched.
8. Reinstall the seat and use the supplied 1/4"-20 x 1.00" 12-Point Bolt to secure the Seat Bolt Mounted Brake Light. Shown in **Figure 3**.
9. Reinstall all necessary parts to connect the negative battery cable to the battery.
10. Test the new Custom Dynamics® Seat Bolt Mounted Brake Light for proper operation for run and brake.

Questions? Email: Info@CustomDynamics.com or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST

Installation Instructions Continued - 2

