

Custom Dynamics® Seat Bolt Mounted Brake Light Installation Instructions



Part Numbers

Patent

CD-SBTL-HD-S, CD-SBTL-HD-R

Patent Pending

Package Contents

Custom Dynamics® Seat Bolt Mounted Brake Light (1)
1/4"-20 x 1.00" 12 point Bolt (1)
Adapter Harness (1)
6" Cable Ties (6)
Instructions (1)



Fitment

1996-2017 Harley-Davidson® Softail Heritage Classic (FLSTC), 2006, 2008-2010 Heritage (FLST), 1996-2017 Fat Boy (FLSTF), 2005-2006 CVO Fat Boy (FLSTFSE), 1996 Heritage Nostalgia (FLSTN), 2005-2017 Deluxe (FLSTN), 1996-1999, 2007-2010 Softail Custom (FXSTC), 1996-2006 Springer (FXSTS), 2007-2009 CVO Springer (FXSTSSE), 1997-2003 Heritage Springer Classic (FLSTS), 2005-2007 Springer Classic (FLSTSC), 2008-2011 Cross Bones (FLSTSB), 1999-2015 Softail Standard (FXST), 1999-2009 Night Train (FXSTB), 2000-2007 Deuce (FXSTD), 2003-2004 CVO Deuce (FXSTDSE), 2010-2017 Fat Boy Lo (FLSTFB), 2016-2017 Fat Boy S (FLSTFBS), 1999-2000 CVO FXR (FXR), 1997-2010 Dyna Super Glide (FXD), 2007-2008 CVO Super Glide (FXDSE), 1999-2005 Super Glide Sport (FXDX), 2001-2003 Super Glide T-Sport (FXDXT), 2005-2014 Super Glide Custom (FXDC), 1997-2017 Low Rider (FXDL), 2016-2017 Low Rider S (FXDLS), 1997-2008, 2010-2017 Wide Glide (FXDWG), 2001-2002 CVO Wide Glide (FXDWG), Super Glide Convertible (FXDS-CONV), 2006-2017 Street Bob (FXDB), 2008-20017 Fat Bob (FXDF), 2009-2010 CVO Fat Bob (FXDFSE), 2012-2016 Switchback (FLD), 2012-2014 Super Glide Custom (FXDC), 1997-2013 Road King (FLHR), 1998-2013 Road King Classic (FLHRC), 1997-2010 Electra Glide Standard (FLHT), 1997-2013 Electra Glide Classic (FLHTC), 1997-2013 Ultra Classic (FLHTCU), 1998-2009 Road Glide (FLTR), 2004-2007 Road King Custom (FLHRS), 2006-2009 Street Glide (FLHX), 2010-2013 Ultra Limited (FLHTK), 2011-2013 Road Glide Ultra (FLTRU), 2000-2001, 2009 CVO Road Glide (FLTRSE), 2011 CVO Road Glide Ultra (FLTRUSE), 2002-2003, 2007-2008 CVO Road King (FLHRSE), 2004-2005 CVO Electra Glide (FLHTCSE), 2006-2013 CVO Ultra Classic (FLHTCUSE).

Note

Seat Bolt Mounted Brake Light is only visible with Tour-Pak® removed.

Suggested Tools

Safety Glasses
Phillips Screwdriver
5/16" 12-Point Socket

Installation

Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Remove all necessary parts to disconnect the negative battery cable from the battery.
2. Remove seat.
3. Unplug the rear lighting connector located under the seat at rear fender. Shown in **Figure 1**.
4. Connect the Adapter Harness in-line to the right rear turn signal connector.
5. Connect the Seat Bolt Mounted Brake Light wire to the Adapter Harness. Shown in **Figure 2**.

Questions? Email: Info@CustomDynamics.com or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST

Installation Instructions Continued - 2

6. Route wire and Seat Bolt Mounted Brake Light back to the seat bolt mount. Shown in **Figure 2**.
7. Secure the wires with the supplied 6" Cable Ties from being cut, frayed or pinched.
8. Reinstall the seat and use the supplied 1/4"-20 x 1.00" 12-Point Bolt to secure the Seat Bolt Mounted Brake Light. Shown in **Figure 3**.
9. Reinstall all necessary parts to connect the negative battery cable to the battery.
10. Test the new Custom Dynamics® Seat Bolt Mounted Brake Light for proper operation for run and brake.

