

Custom Dynamics® LED Center Windshield Trim Installation Instructions



Part Number

CD-SG23-CWT-B

Package Contents

Custom Dynamics® LED Center Windshield Trim (1)
6" Cable Ties (4)
Cable Tie Holders (2)
Magnet (1)
Instructions (1)



Fitment

2023-2026 Harley-Davidson® CVO Street Glide (FLHXSE), 2025 Street Glide Ultra (FLHXU), 2024-2026 Street Glide (FLHX), 2026 Street Glide Limited (FLHXL), CVO Street Glide Limited (FLHXLSE), CVO Street Glide ST (FLHXSTSE), Street Glide 3 Limited (FLHLT) and CVO Street Glide 3 Limited (FLHLTSE).

Suggested Tools

Safety Glasses
Fender Protection
T25 TORX Socket or Handle Driver

Installation

Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Remove all necessary parts to disconnect the negative battery cable from the battery.
2. Remove windshield, vent cover, vent and outer fairing and disconnect the headlight. Shown in **Figure 1**.
3. Place the outer fairing on a bench to work on and not cause damage.
4. Install the new Custom Dynamics® LED Center Windshield Trim in the fairing vent opening and press into opening flush to the vent. Shown in **Figures 2 and 3**.
5. Route the wires from the LED Center Windshield Trim on both sides to the space between the T25 TORX bolt and plastic vent bottom. Shown in **Figures 4 and 5**.
6. Route the wires inside the outer fairing down to the OEM turn signal connectors on both sides and plug inline with OEM turn signals and secure with supplied Cable Tie Holders and Cable Ties. Shown in **Figures 6 and 7**.
7. Reinstall the outer fairing back on the motorcycle and plug in the headlight.
8. Install the vent back onto the motorcycle. Shown in **Figure 8**.
9. Remove and discard OEM windshield rubber holders and install the vent top cover by sliding into the LED Windshield Trim. Shown in **Figures 9, 10 and 11**.
10. Reinstall the windshield. Shown in **Figure 12**.
11. Reconnect the negative battery cable to the battery and reinstall all necessary parts.
12. Test the new Custom Dynamics® LED Windshield Trim for proper operation.

Questions? Email: Info@CustomDynamics.com or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST

Installation Instructions Continued - 2

