



Custom Dynamics® 36” Speedo Wire Extension Harness Installation Instructions

We thank you for purchasing the Custom Dynamics® 36” Speedo Wire Extension Harness. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: CD-ST-SP-HARN

Package Contents:

- 36” Speedo Wire Extension Harness (1)
- Instructions (1)
- 4” Cable ties (6)



Fits: 2018-2020 (FXBB) STREET BOB, 2021-2024 (FXBBS) STREET BOB 114, 2018-2019, 2023 2024 (FXBR) BREAKOUT, 2018-2022 (FXBRS) BREAKOUT 114, 2018 (FXBRS ANX) BREAKOUT 114 ANNIVERSARY, 2019 (FXDRS) FXDR 114, 2022-2024 (FXLRST) LOW RIDER ST, 2022 (FXRST) LOW RIDER EL DIABLO, 2020-2024 (FXST) SOFTAIL STANDARD.

Installation:

Note: This product is intended as a plug and play extension for the speedo wire harness for installing taller handlebars.

1. Remove all necessary parts to access the battery and disconnect the battery negative cable.
2. Disconnect OEM speedo wire harness at the back of speedo and disconnect opposite end of harness located at the front of the fuel tank on the frame backbone in a rubber grommet.
3. Connect speedo extension harness to back of speedo and then back to frame backbone connection through rubber grommet.
4. Secure speedo harness wire with cable ties to prevent damage and replace all necessary parts to reconnection negative battery cable.
5. Check all functions of speedo.



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST