



Custom Dynamics® SXS Turn Signal Kit Installation Instructions

We thank you for purchasing the Custom Dynamics® SXS Turn Signal Kit. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: CD-SXS-GEN
US Patent: D993198

Package Contents:

- CD-SXS-FTS-AW (1)
- SXS-TS-SW-1 (1)
- CD-ATC-6 (1)
- GEN-SMART-TPU-GEN (1)
- Instructions (1)

Fits: 2018-2026 Polaris General™ 1000 & XP 1000 Models with and without OE Ride Command.



ATTENTION



Please read before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Note: Please refer to each individual set of included Instructions for specific notes and warnings for each part. Always refer to your manufacturers service manual if unsure of any procedure.

Important: It is recommended that the installation of this product should be performed in a controlled environment with constant temperature of 70F or above to allow proper adhesion. Allow 24 hours before riding or washing the vehicle.

Installation:

1. Disconnect the negative battery cable from the battery.
2. Install the CD-ATC-6. Follow the procedure in the included instructions with the CD-ATC-6 for specifics on installation and wiring connections.
3. Install the SXS-TS-SW-1. Follow the procedure in the included instructions with the SXS-TS-SW-1 for specifics on installation and wiring connections.
4. Install the GEN-SMART-GEN Follow the procedure in the included instructions with the GEN-SMART-GEN for specifics on installation, wiring connections and programming.
5. Install the CD-SXS-FTS-AW. Follow the procedure in the included instructions with the CD-SXS-FTS-AW for specifics on installation, mounting and wiring connections
6. Reconnect the negative battery cable to the battery.
7. Test the Custom Dynamics® SXS Turn Signals for proper operation.

Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST