



Custom Dynamics® High Mount Tour-Pak LED Light Installation Instructions

We thank you for purchasing the Custom Dynamics® High Mount Tour-Pak LED Light. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: CD-TP-LID-BS CD-TP-LID-BR
CD-TP-LID-CS CD-TP-LID-CR

Package Contents:

- Tour-Pak LED Light (1)
- BCM Y Harness Adapter (1)
- 6" Cable Ties (6)
- Cable Tie Holders (2)
- Wire Keepers (4)
- Instructions (1)

Fits: 2014-2024 Harley-Davidson® Ultra Limited (FLHTK), 2020-2024 Road Glide Limited (FLTRK), 2022-2023 CVO™ Road Glide Limited (FLTRKSE), 2014-2019 Electra Glide Ultra Classic (FLHTCU), 2015-2016 Ultra Classic Lo (FLHTCUL) & CVO™ Road Glide Ultra (FLTRUSE), 2016-2019 Road Glide Ultra (FLTRU), 2015-2018 Ultra Limited Lo (FLHTKL), 2014-2021 CVO™ Limited (FLHTKSE), 2014-2025 Tri Glide (FLHTCUTG) and 2020-2022 CVO™ Tri Glide (FLHTCUTGSE) with OEM King Tour Pak.

Also fits 2014-2023 Harley-Davidson® Street Glide (FLHX), Street Glide Special (FLHXS), 2015-2023 Road Glide (FLTRX), Road Glide Special (FLTRXS), 2017-2025 Road King Special (FLHRXS), 2014-2022 Road King (FLHR), 2022-2023 Street Glide ST (FLHXST), Road Glide ST (FLTRXST), 2015-2022 CVO™ Street Glide (FLHXSE), 2018-2022 CVO™ Road Glide (FLTRXSE), 2019-2022 Electra Glide Standard (FLHT) and 2014 CVO™ Road King (FLHRSE) with add-on King or Chopped style Tour Pak.

Typically 2014-2022 Road King, 2019-2022 Electra Glide Standard, 2022-2023 Street Glide ST & Road Glide ST, 2014-2015 CVO™ Limited and 2015 CVO™ Road Glide Ultra, 2014-2022 Street Glide CVO™, 2018-2022 Road Glide CVO™ & 2014 Road King CVO™ function as Run/Turn only.



Installation:

1. Remove seat and disconnect negative battery cable from the battery.
2. On all models except Tri Glide® models, locate and unplug the lighting connector to the rear fender. On Tri Glide® Models locate and unplug the Tour-Pak® lighting connector.
3. On all models except Tri Glide® models, plug the supplied BCM Y Harness Adapter, in-line, into the rear lighting harness and into the motorcycles main wiring harness. On all Tri Glide® models, plug the supplied BCM Y Harness Adapter, in-line, into the Tour-Pak® lighting harness.
4. Remove the passenger backrest from the Tour-Pak by removing the 3 securing nuts on the inside of the Tour-Pak lid. Save the hardware as it will be used for reassembly.
5. Clean the surface area where the Tour-Pak High Mount LED Light will be installed on top of the Tour-Pak lid; remove any grease, wax or debris. Wipe the surface area with denatured alcohol and allow to dry.
6. Test fit the Tour-Pak High Mount LED Light on the Tour-Pak lid, use a grease pencil to make any alignment marks.
7. Remove the red protective film of the 3M™ tape from the back of the Tour-Pak High Mount LED Light. Firmly press the Tour-Pak High Mount LED Light into place using the grease pencil marks in Step 6 as your guide. Apply pressure evenly over the Tour-Pak High Mount LED Light for one minute to ensure the tape is applied evenly.
8. Route the wire from the Tour-Pak High Mount LED Light down the front of the Tour-Pak Lid using the supplied Wire Keepers and Cable Tie Holders as shown in **Figures 1 and 2 on Page 2**. Secure the wire from being cut, frayed or pinched behind the passengers backrest when installed. Be sure to leave slack in the wire to allow the TOUR-Pak lid to fully open as shown in **Figure 3 on Page 2**.



ATTENTION

Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on motorcycle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure motorcycle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Important: Ambient install temperature must be 60 degrees F or higher. Allow 24 hours for tape to cure before washing or prolonged use of motorcycle.

Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2

Installation Continued:

9. Continue routing the wire towards the BCM Y Harness. Secure the wire from being cut, frayed or pinched under the seat when installed.
10. Connect the Tour-Pack High Mount LED Light to the BCM Y Harness Adapter.
11. Reconnect the negative battery cable to the battery.
12. Reinstall the seat and the passengers backrest.
13. Perform a BCM sync by turning the ignition on, turn the 4 way hazards on, turn the ignition off. Allow the 4 way hazards to run for 3-4 minutes. Turn the ignition on. Turn the 4 way hazards off. Turn the ignition off. Test for proper operation.
14. Test the Custom Dynamics® High Mount Tour-Pak LED Light for proper operation.

