



Custom Dynamics® H4 LED Headlight Adapter Harness Installation Instructions

We thank you for purchasing the Custom Dynamics® H4 LED Headlight Adapter Harness. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: H4-TOUR-ADPT

Package Contents:

- H4 LED Headlight Adapter Harness (1)
- Instructions (1)



Fitment: 2014-2024 Harley-Davidson® Ultra Limited (FLHTK), 2014-2023 Street Glide (FLHX), Street Glide Special (FLHXS), 2022-2023 Street Glide ST (FLHXST), 2015-2022 CVO™ Street Glide (FLHXSE), 2014-2019 Electra Glide Ultra Classic (FLHTCU), 2015-2016 Ultra Classic Low (FLHTCUL), 2015-2018 Ultra Limited Low (FLHTKL), 2014-2021 CVO™ Limited (FLHTKSE), 2019-2022 Electra Glide Standard (FLHT), 2014-2025 Tri Glide Ultra (FLHTCUTG), 2020-2022 CVO™ Tri Glide (FLHTCUTGSE), 2014 CVO™ Road King (FLHRSE) and 2021-2025 Road King Special (FLHRXS).

Installation:

1. Remove the seat and disconnect the negative battery cable from the battery.
2. Remove the OEM headlight, please refer to the instructions in the service manual for your motorcycle.
3. Disconnect the OEM headlight harness from the main harness and discard.
4. Connect the H4 LED Headlight Adapter Harness to the main harness connector.
5. Connect the headlight to the H4 LED Headlight Adapter Harness. **Note: The blue wire with the spade not connected to the H4 Connector is not used in some cases, it is for the position light on some headlights.**
6. Follow the Installation Instructions with the new LED Headlight to complete installation.
7. Reconnect the negative battery cable to the battery and reinstall the seat.
8. Test the new LED Headlight for proper operation.



ATTENTION



Please read all information below before installation

Warning: Disconnect negative battery cable from the battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on motorcycle.

Safety First: Make sure the motorcycle is parked on a level surface and motorcycles mechanical components are cool to the touch.

Note: These instructions reference the use of a Service Manual. A manual is required for this installation. Please contact the manufacturer to obtain a service manual if you do not have one.

Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST