

Custom Dynamics® Low Rider S Headlight Mounting Bracket Installation Instructions



Part Numbers

MOUNT-V2-FXLRS

Package Contents

Custom Dynamics® LRS Headlight Mounting Bracket (1)
Instructions (1)



Fitment

2020-2026 Harley-Davidson® Low Rider S (FXLRS).

Note

Compatible with Custom Dynamics® 5.75" Softail Headlight Bucket: CD-18ST-BUCKET (**sold separately**).

Suggested Tools

Safety Glasses
1/4" Allen Socket
9/16" Open End Wrench

Installation

Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Remove all necessary parts to disconnect the negative battery cable from the battery.
2. Remove OEM Headlight assembly, headlight mount and unplug headlight connector. Save OEM mounting bolts for reuse.
3. Mount the Custom Dynamics® Low Rider S Headlight Mounting Bracket using the OEM mounting bolts.
4. Install the Custom Dynamics® Headlight Bucket and LED Headlight (**sold separately**) to the Custom Dynamics® Low Rider S Headlight Mounting Bracket. Refer to the Headlight Bucket and Headlight instructions for proper installation.
5. Reconnect the negative battery cable to the battery and reinstall all necessary parts.
6. Test the new Custom Dynamics® or ProBEAM® LED Headlight for proper operation.

Questions? Email: Info@CustomDynamics.com or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST