



Custom Dynamics® ProBEAM® LED Indian Scout Bobber Rear Turn Signals™

We thank you for purchasing the Custom Dynamics® ProBEAM® Scout Bobber Rear Turn Signals! Our LEDs offer maintenance free service and higher visibility. Our ProBEAM® product line utilizes the latest technology and automotive grade components to ensure the highest level of reliable service. Custom Dynamics® offers one of the best warranty programs and customer support in the industry. If you have any questions during the installation of this product please call us at 1(800) 382-1388.

Part Numbers: PB-INDBOB-RR-BR

Package Contents:

- ProBEAM® Scout Rear Turn Signals (2)
- Instructions (1)



Fitment: 2018-2023 Indian Motorcycles® Scout Bobber, Scout Bobber Sixty, Scout Bobber Twenty, Scout Rogue, Scout Rogue Sixty.

Custom Dynamics® ProBEAM® Scout Turn Signals can **ONLY** be used with ProBEAM® Bullet Style Turn Signal Lenses. Bullet Bezel Turn Signal Adapters are not compatible with ProBEAM® Scout Turn Signals.



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Installation:

1. Remove motorcycle seat and disconnect the negative battery cable from the battery. Consult your owners manual if unsure of this process.
2. Disconnect the left and right rear turn signal harnesses from under the seat from the bikes rear left and right turn signal connectors.
3. Following the procedure in your manufacturers service manual, disconnect and remove the rear fender struts from the rear fender.
4. Lay the fender struts on a protected surface and unbolt both the wire retainer and turn signals from each strut. Remove turn signal and wiring. Shown in Figure 1.



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2

Installation Continued:

5. Install the new ProBEAM turn signals using the OEM bolt removed in Step 4.
6. Route and secure the wires through wire retainers. Shown in Figure 2.
7. Locate the black 2 pin license plate light connector under the right side strut and connect to the 2 pin connector on the right side ProBEAM turn signal harness.
8. Reinstall the left and right fender strut assemblies to the rear fender.
10. Connect the connector from each turn signal housing to bike's associated left or right rear turn signal connector. Shown in Figure 3.
11. Using the provided wire ties, secure the wiring harnesses to prevent them from becoming frayed or damaged.
12. Reconnect the negative battery cable to the battery and install the seat.
13. Test all lighting for proper operations before riding

2



3

