

Custom Dynamics® ProBEAM® Accessory Mounting Clamp Installation Instructions



We thank you for purchasing the Custom Dynamics® ProBEAM® Accessory Mounting Clamp. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1 (800) 382-1388.

Part Numbers:	PB-10-B	PB-10-C
	PB-15-B	PB-15-C
	PB-20-B	PB-20-C
	PB-125-B	PB-125-C
	PB-175-B	PB-175-C



Package Contents:

- ProBEAM® Accessory Clamps (2)
- 3 mm Allen Head Screws (4)
- 2.5 mm Set Screws (2)
- 3 mm Hex Wrench (1)
- 2.5 mm Hex Wrench (1)
- Instructions (1)

Fitment: Universal 5/16" mounting hole.
H-D® engine guards use 1.25" clamps.



ATTENTION



Please read all Information below before Installation

Warning: Remove seat and disconnect the negative battery from the battery; Failure to do so may result in electrical shock, injury or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on motorcycle.

Safety First: Make sure the motorcycle is parked on a level surface and motorcycles mechanical components are cool to the touch.

Note: Always wear appropriate safety gear including safety glasses when soldering or performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Please read all instructions before starting project.

Note: Mounting studs are 5/16" in diameter, please verify your mounting clamp hole before installation.

Installation:

1. Remove the seat and disconnect the negative battery cable from the battery.
2. Install the Custom Dynamics® ProBEAM® Accessory Mounting Clamps on motorcycles engine guard by fitting both clamp halves around the tube and using supplied 3 mm Allen Head Screws to fasten clamp using supplied 3 mm Hex Wrench to tighten and finally use the supplied 2.5 mm Set Screws and 2.5 mm Hex Wrench to lock them in place.
3. Install the Custom Dynamics® ProBEAM® LED Halo Fog Lamps or other Custom Dynamics® Accessories (**sold separately**) to the ProBEAM® Accessory Mounting Clamps with a maximum diameter of 5/16" hole. Refer to the Custom Dynamics® Accessories instructions for installation. Custom Dynamics® ProBEAM® Accessory Mounting Clamps with Custom Dynamics® ProBEAM® LED Halo Fog Lamps shown in **Figure 1**.



Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST