Custom Dynamics® Plasma Rod™ Adapter Harness Installation Instructions

Part Numbers

PR-MPR-26T

Package Contents

PR-MPR-26T Plasma Rod™ Adapter Harness (1)
Instructions (1)



Fitment

2026 Harley-Davidson® CVO Street Glide Limited (FLHXLSE), Street Glide Limited (FLHXL) and Road Glide Limited (FLTRXL).

Suggested Tools

Safety Glasses

Installation

Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

Note

This is compatible with PR-PLUG-DC, PR-PLUG-R, and CD-PR-8 Plasma Rods.
If used with Red (PR-PLUG-R or CD-PR-8), Plasma Rods will connect to this harness utilizing the 4-pin JAE connector. The 2-pin white plug wire section should be removed from the Plasma Rod.

1. Remove the seat and all necessary parts to disconnect the negative battery cable from the battery.
2. Locate and unplug the rear lighting harness connector near the rear fender.
3. Plug the supplied PR-MPR-26T Plasma Rod™ Adapter Harness, in-line, into the rear lighting harness and into the motorcycles main wiring harness.
4. Connect the Plug and Play Plasma Rods™ **(sold separately)** to the installed PB-MPR-26T Plasma Rod™ Adapter Harness. Connect Left Plasma Rod™ to the 4 pin connector of the PB-MPR-26T Plasma Rod™ Adapter Harness with the violet wire. Connect Right Plasma Rod™ to the 4 pin connector of the PB-MPR-26T Plasma Rod™ Adapter Harness with the brown wire.
5. Secure wires under the seat to prevent the wires from being cut, frayed, or pinched.
6. Reconnect the negative battery cable to the battery and reinstall the seat and all necessary parts.
7. Test the Custom Dynamic® Plasma Rods™ for proper operation.

Questions? Email: Info@CustomDynamics.com or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST