



## Custom Dynamics® Plug and Play Plasma Rod™ Adapter Installation Instructions

We thank you for purchasing the Custom Dynamics® Plug and Play Plasma Rod™ Adapter. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Numbers:** PR-MPRSEQ-SS8

### Package Contents:

- SS8 Dual Color Plasma Rod™ Adapter w/ Plugs (1)
- Instructions (1)

**Fits:** 2009-2013 Harley-Davidson® CVO™ Street Glide (FLHXSE) and CVO™ Road Glide Custom (FLTRXSE), 2013 CVO™ Road King (FLHRSE) with PR-PLUG-DC Plug and Play Dual Color Plasma Rods™ (**Sold Separately**).



## ATTENTION

Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on motorcycle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure motorcycle is on level surface, secure and cool.

**Important:** This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

**Note:** The SS8 Plasma Rod™ Adapter must be plugged into the output (behind) any Smart Signal Stabilizer™/load equalizer or any brake strobe modules.

### Installation:

1. Remove all necessary parts to disconnect the negative battery cable from the battery.
2. Locate and unplug the rear lighting harness connector to the rear fender.
3. Plug the supplied SS8 Plasma Rod™ Adapter, in-line, into the rear lighting harness and into the motorcycles main wiring harness. **Note: The order of installation, front to back, will be motorcycles SS8 main wiring harness, Smart Signal Stabilizer™/Load Equalizer (if installed), brake strobe module (if installed), SS8 Plasma Rod™ Adapter, Run/ Brake/Turn module (if installed) and then the motorcycles rear lighting harness.**
4. Connect the Plug and Play Plasma Rods™ (**Sold Separately**) to the installed SS8 Plasma Rod™ Adapter. Connect Left Plasma Rod™ to the connector of the SS8 Plasma Rod™ Adapter with the violet wire. Connect Right Plasma Rod™ to the connector of the SS8 Plasma Rod™ Adapter with the brown wire.
5. Secure all wires with cable ties to prevent wires from becoming cut, frayed or pinched.
6. Reconnect the negative battery cable to the battery and reinstall all necessary parts.
7. Test the Custom Dynamics® Plasma Rods™ for proper operation.

Questions? Email: [info@CustomDynamics.com](mailto:info@CustomDynamics.com) or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST