

# Custom Dynamics® Shark Demon® Off Road Fog Light Harness Installation Instructions



## Part Numbers

SD-OR-FOG-HARN

## Package Contents

SD-OR-FOG-HARN Harness (1)  
10" Cable Ties (5)  
Solder Seal Sleeves (2)  
Instructions (1)



## Fitment

Universal 12VDC negative ground systems, SXS & UTV.

### Note

Use with CD-OR-SWITCH Rocker Switch (**sold separately**).

## Suggested Tools

Safety Glasses  
Wire Strippers/Crimping Tool  
Heat Gun

## Installation

### Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Remove all necessary parts to disconnect the negative battery cable from the battery.
2. Connect the red wire to a switched 12VDC power source **[+]** and the black wire to a ground **[-]** from the SD-OR-FOG-HARN Harness using the supplied Solder Seal Sleeves.

### Note

Use with CD-OR-SWITCH Rocker Switch (**sold separately**).

3. Find a suitable location for the CD-OR-SWITCH (**sold separately**). Refer to CD-OR-SWITCH installation instructions for proper operation.
4. Use supplied Cable Ties to secure all wires from being cut, frayed or pinched.
5. Make sure Fog Light JAE connectors from SD-OR-FOG-HARN Harness are free and easily accessible for the Fog Lights to be connected to. Refer to the Custom Dynamics® Shark Demon® Fog Lights (**sold separately**) installation instructions for the Fog Light installation.
6. Reconnect the battery negative cable to the battery and reinstall all necessary parts.
7. Test the Custom Dynamics® Shark Demon® Fog Lights for proper operation.

Questions? Email: [Info@CustomDynamics.com](mailto:Info@CustomDynamics.com) or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST