

# Custom Dynamics® Shark Demon® Fog Light Rock Guard Installation Instructions



## Part Number

SD2-FOG-GUARD-C

## Package Contents

Shark Demon® Fog Light Rock Guard, Clear (1)  
Instructions (1)



## Fitment

Compatible with Custom Dynamics® Shark Demon® Fog Lights SD-FOG-1W, SD-FOG-1Y, SD-FOG-2W, SD-FOG-2Y, SD-FOG-3W, SD-FOG-3Y, SD-FOG-4W, SD-FOG-4Y, SD-FOG-5W, SD-FOG-5Y, SD-FOG-6W, SD-FOG-6Y, SD-OR-FOG-W and SD-OR-FOG-Y (**sold separately**).

### Important

For Off Road use only. Do not trailer vehicle backwards with Rock Guards installed, wind could blow Shark Demon® Fog Light Rock Guard off Shark Demon® Fog Light.

## Installation

### Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Install Shark Demon® Fog Light Rock Guard by snapping into place over the Shark Demon® Fog Light. Shown in **Figure 1**.



2. Test the Custom Dynamics® Shark Demon® Fog Light with Shark Demon® Fog Light Rock Guard for proper operation.

Questions? Email: [Info@CustomDynamics.com](mailto:Info@CustomDynamics.com) or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST