

Custom Dynamics® Shark Demon® 2 Off Road Rock Guard Installation Instructions



Part Number

SD2-GUARD

Package Contents

Shark Demon® 2 Off Road Rock Guard, Clear (1)
Instructions (1)



Fitment

Compatible with Custom Dynamics® Shark Demon® 2 Off Road Auxiliary LED Lights, SD2-OR-Y and SD2-OR-W (**sold separately**).

Important

For Off Road use only. Do not trailer vehicle backwards with Rock Guards installed, wind could blow Shark Demon® 2 Rock Guard off Shark Demon® 2 Off Road Auxiliary LED Light.

Installation

Warning

Rider and passenger safety depend upon the correct installation of this kit. Use the appropriate service manual procedures. If the procedure is not within your capabilities or you do not have the correct tools, have a qualified technician perform the installation. Improper installation of this kit could result in death or serious injury.

1. Install Shark Demon® 2 Rock Guard by snapping into place over the Shark Demon® 2 LED Light. Shown in **Figure 1**.



2. Test the Custom Dynamics® Shark Demon® 2 Off Road Auxiliary LED Light with Shark Demon® 2 Rock Guard for proper operation.

Questions? Email: Info@CustomDynamics.com or Call us at: 1(919)554-0949 M-TH 8:30AM-5:30PM, F 9:30AM-5:30PM EST