



Custom Dynamics® TruFlex® Integrated Plate Frame Installation Instructions

We thank you for purchasing the Custom Dynamics® TruFlex® Integrated Plate Frame. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: TF05-HD-B TF05-HD-C

Package Contents:

- TruFLEX® License Plate Frame w/Converter (1)
- Mounting Hardware Kit (1)
- HD Y-Adapter (1)
- 4" Cable Ties (10)
- Instructions (1)



Fits: 1996-2010 Softail® (Except Rocker), 1997-2011 Dyna®, 1999-2003 Sportster®, 1997-2013 Harley-Davidson® Electra Glide, Ultra Classic, Ultra Limited models (including CVO™), Road King (FLHR), Road King Classic (FLHRC), Road Glide Ultra (FLTRU) and Road Glide Ultra CVO™ (FLTRUSE), 1997-2009 Road Glide Standard (FLTR) and 2006-2009 Street Glide (FLHX).

Note: Radius License Plate Frame Mount required for installation (sold separately).

Installation:

1. Remove seat and disconnect the negative battery cable from the battery.
2. Locate and unplug the lighting connector for the rear fender.
3. Plug the supplied HD Y-Harness Adapter in-line with the rear lighting harness and the motorcycles main wiring harness.
4. Mount the TruFLEX® License Plate Frame using the supplied Hardware Kit. **Note:** For proper fitment the license plate may need to be cut or notched to allow the wiring from the TruFLEX® License Plate Frame to pass through.
5. Route the wiring from the TruFLEX® License Plate Frame to the HD Y-Harness. Secure wires with supplied Cable Ties to prevent the wires from being cut, frayed or pinched.
6. Connect the TruFLEX® License Plate Frame left side (violet) wire and right side (brown) wire to the HD Y-Harness connectors.
7. Reconnect the negative battery cable to the battery and reinstall the seat.
8. Test the new Custom Dynamics® TruFLEX® License Plate Frame for proper operation.



ATTENTION

Please read all Information below before Installation

Important: Disconnect the negative battery cable from the battery; Failure to do so may result in electrical shock, injury or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on motorcycle.

Important: For safety make sure the motorcycle is parked on a level surface motorcycles mechanical components are cool to the touch.

Note: Always wear appropriate safety gear including safety glasses when soldering or performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Please read all instructions before starting project.

Note: For proper fitment, the license plate may need to be cut or notched to allow the wiring from the license frame to pass through.

Important: This product is intended for use as auxiliary lighting only. Not intended to replace OEM lighting installed on the motorcycle and should not be used for that purpose. This product must be wired so that it does not interfere with any OEM lighting.

Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST