



Custom Dynamics® SXS Horn Kit with Bracket Installation Instructions

We thank you for purchasing the Custom Dynamics® SXS Horn Kit with Bracket. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: CD-HORN-SXS

Package Contents:

- 6" Cable Ties (6)
- Cable Tie Mounts (4)
- SXS Horn Harness with Switch (1)
- Horn Y-Harness (1)
- Dual Electromagnetic Horn (Horn, Flat Brackets and Nut) (1)
- Dual Horn Cowbell Bracket (1)
- Instructions (1)



Fitment: Universal, 12VDC Honda, Polaris, CanAm, Yamaha, & Kawasaki SXS models.

Installation:


1. Disconnect the negative battery cable from the battery.
2. The Horn labeled with "H" is the High. The Horn Labeled with "L" is the Low. Connect the long black [-] wire and long red [+] wire of the Horn Y-harness to the High tone horn terminals. Shown in **Figure 3 on Page 2**.
3. Mount both Dual Electromagnetic Horns to the Dual Horn Cowbell Bracket using the supplied nuts. The High tone Horn will mount on the left side and the Low tone Horn will mount on the right side. Reference orientation of the Horns shown in **Figure 1**. **Note: the Flat Brackets included with the horns will not be used.**
4. Connect the remaining black [-] and red [+] wires of the Horn Y-Harness to the Low Horn. Shown in **Figure 3 on Page 2**. **Note: make sure that the female spade connectors that are connected to the horns do not touch the Dual Horn Cowbell Bracket; bend the horn's male spade connectors slightly if necessary.**

⚠ ATTENTION ⚠

Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.




Questions? Email: info@CustomDynamics.com or Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2

Installation Continued:

5. Mount the Dual Horn Cowbell Bracket to the vehicle.
6. Mount SXS Horn Harness Switch. The dimensions for the Switch are shown in **Figure 2**.
7. Route wire "B" from the battery to the dash. Connect the female terminal of wire "B" to terminal 2 on the SXS Horn Harness Switch. Shown in **Figure 3**.
8. Connect the female terminal of wire "C" to Terminal 3 on the Switch. Shown in **Figure 3**.
9. Route wire "C" from Terminal 3 on switch of the towards the Horn. Connect to the red wire [+] on Horn Y- Harness. Shown in **Figure 3**.
10. Route wire "A" from the Negative battery post towards the horn. Connect to the black [-] wire on Horn Y-Harness. Shown in **Figure 3**.
11. Secure all wiring to prevent the wire from becoming pinched or damaged with the supplied Cable Ties and Cable Tie Mounts.
12. Connect the ring terminal from harness "B" to the positive battery post. Shown in **Figure 3**.
13. Connect the ring terminal from harness "A" and Negative battery cable to the negative battery post. Shown in **Figure 3**.
14. Test the Custom Dynamics® SXS Horn Kit for proper operation before riding.



3

Optional Switch Illumination (wiring not included):

Terminal 8 & 7: Ground

Terminal 6: Switched 12 V +

